


Rear Endlinks Kit Installation Instructions SPL RE FRS



Torque the Flange Nuts (3) attaching the endlinks to the sway bar to 40 **ft.-lbs. DO NOT OVERTORQUE!**

Torque the Jam Nut (5-length setting of endlink) to 20-30 **ft.-lbs.**

SPL Parts is not liable for any issues due to overtorque.

Install endlink. To eliminate sway bar preload (recommended), leave one endlink bolt disconnected (other endlink bolts should be connected). Place car (all 4 wheels) on flat ground. Adjust the length of the disconnected endlink until the bolt inserts easily into the sway bar. That will be the length setting to use. Assemble and tighten that endlink accordingly.

Make sure that the endlinks have good articulation after tightening down the Jam Nuts (5). Grab the Turnbuckle (1) and rotate left to right, the entire endlink should be able to rotate back and forth in an approx. 50 deg range. If not, loosen one Jam Nut and adjust the bearing, then tighten the Jam Nut making sure to keep the bearings in alignment.



ONE-YEAR LIMITED WARRANTY AND DISCLAIMER

All SPL brand products are intended for **Off Road Use Only** and carry a one year limited warranty. See below for details. All other branded products carry their respective manufacturer warranty.

SPL PRO suspension products warranted to be free of defects in material and workmanship for one (1) year from the date of purchase.

If a product fails to meet specifications, SPL PARTS INC will, at its election, repair, replace, or make appropriate adjustment, if SPL PARTS INC determines to its satisfaction that the product is defective in material or workmanship, i.e. contains a defect arising out of the manufacture of the product and not a defect caused by other circumstances, including, but not limited to accident, misuse, abuse, unforeseeable use, neglect, alteration, improper installation, improper adjustment, improper repair, or failure caused by other equipment or interaction with other equipment. SPL PARTS INC is not responsible for labor charges, removal charges, installation, or other incidental or consequential costs. In no event shall the liability of SPL PARTS INC exceed the purchase price of the product.

SPL PARTS INC makes no other warranties, either expressed or implied, including limitation warranties as to merchantability or fitness for a particular purpose. SPL PARTS INC shall not be liable for, and buyer assumes all risk of, any advice or failure to provide advice by SPL PARTS INC to buyer regarding the product or use and installation of product. SPL PARTS INC shall not be liable for any special, incidental or consequential damages.

If the purchaser of the product shall fail to pay when due any portion of the purchase price, or fail to meet any terms required under contract agreed on at time of purchase, all warranties and remedies granted may be terminated.

Using any SPL arm as a tie/strap down point for a dyno session or transport will void the warranty.